

Hi3516AV300 50X50mm双层板接线手册v1.0

接口定义:

出厂默认配置:

IP: 192.168.1.168
 PW: 123456
 Rtsp://192.168.1.168/stream_0

电源网络接口:

- 1.DC12V
- 2.GND
- 3.RJ45_1(TX+)
- 4.RJ45_2(TX-)
- 5.RJ45_3(RX+)
- 6.RJ45-6(RX-)
- 7.Link Lamp
- 8.ACT Lamp

USB 接口:

1. 5V Out
2. USB_DM
3. USB_DP
4. GND

音频输出接口:

1. SPK+
2. SPK-

调试接口:

1. 3V3
2. UART0_TX
3. UART0_RX
4. GND

IR-CUT 接口:

- 1.IR-CUT 1
- 2.IR-CUT 2

红外光板接口:

- 1.光板控制信号输入
- 2.GND
- 3.恒流 IC PWM

电源接口:

1. DC12V
2. GND

功能接口:

- 1.WG_IN0
- 2.WG_IN1
- 3.GND
- 4.WG_OUT0
- 5.WG_OUT1
- 6.GND
- 7.Reset
- 8.GND
- 9.Alarm IN
- 10.Relay NO
- 11.Relay COM
- 12.Relay NC
- 13.RS485_A
- 14.RS485_B

MIC 接口:

1. MIC+
2. MIC-

补光灯接口:

1. Infrared LED+
2. Infrared LED-
3. White light LED+
4. White light LED-

自动IRIS镜头接口:

1. Driver-
2. Driver+
3. Damp+
4. Damp-

